

## (f) danew 14 rue de la Perdrix,

93420 Villepinte, FRANCE www.danew.com

status bar will display flight mode when the SIM. card is disabled. Dual card of the phone supports Mobile, Unicom, Telecom, and supports dual 4G function, but the dual 4G function can not work at the same

WLAN switch and settings
Touch the WLAN icon, it will automatically search for the available
network, network without password can be directly connected, and
network with password requires password input. Open the WLAN and then open the offline mode, WLAN will be automatically shut down; Open flight mode to connect WLAN, WLAN can be used normally.

automatically search for Bluetooth.

Mobile traffic usage
To monitor the mobile traffic and set the mobile data traffic restrictions,

Flight mode
Touch to turn on/off the flight mode. The related services of mobile

Network sharing and portable hot spots
You can share the network by the USB data line, Bluetooth and the
establishment of WLAN hot spot. To click this option, you can set the name of the WLAN shared network, password, etc.

Enter the mobile network settings interface, including: a Data roaming,

GPRS data priority mode Checked by default, phone priority. When you use the GPRS Internet, the phone can be in normal use.

Manual Konnect 560 CINEPIX

Thanks for using Danew Konnect 560 wich will bring you high-quality

## Instruction manual

- User manual describes various features of this product, usage and precautions. • In order to ensure your safety and use the product correctly, please
- read the user's manual carefully before using your mobile phone. In order to ensure your safety and use the product correctly, please read the user's manual carefully before using your mobile phone. Description of the user manual is based on the default settings for this product.
- Use the phone to send and receive information, upload and download, automatic synchronization or location services and other functions may generate additional costs, in order to avoid additional costs, please select the appropriate data charges plan. More information, please contact the service provider.
- Procedures and functions may vary by region or hardware specifications. Danew is not responsible for the performance by the third party application.
- This user manual is updated in March 11, 2016. Please keep it properly for future reference.

## Copyright

Copyright 2016 Danew

This manual is protected by international copyright law Nithout Danew written permission shall not be reproduced, distributed, transferred or transmitted in any form or manner (electronic or mechanical), including copying, recording, or storting in any storage and



- approved accessories. The mobile phone is with a non-removable builtin battery, you can replace the battery only by the company authorized
- The battery can be charged repeatedly, but the battery is consumption good. If there's a significant reduction in the standby time of the phone, do not replace the battery yourself, please contact the company's
- authorized service center to replace the original battery. • The phone should be charged before the first use, you can charge the
- phone by charger or through the USB data cable to connect the device to the computer to charge the battery. The phone will gradually discharge if it's long-term unused. Before
- normal use, the phone have to be recharged. immediately when you just plug in the charger, this is a normal phenomenon. Please continue to charge for some time, and then boot it
- For the new or long-term unused battery, we suggest that you charge the battery. When the charge is completed, please unplug the charger
- The new battery or long-term unused battery needs to be fully charged and discharged after several times in order to achieve its best state.

### Method of using the charger

and charging data line in time.

In order to improve the charging efficiency and ensure the safety of charging, please use 220V alternating current. Connect the charger and charging data line of the phone and then insert them into the power socket. Do not allow the charging data line to be damaged or affected. Connect the charging data line to the phone charging identification for charging. When the charge is completed, please unplug the charger and charging data line in time. In order to avoid the danger of electric shock, please unplug it from the power source before cleaning the charger. For safety, do not use the charger in the outdoor or damp

## Quick Guide

Slide open the projection lens cover, to open the projection

you can open the projection, it will bring more fun.

- automatically closed.
- Projection bright and low light mode can be set up)
- Click the "projection" quick open / close icon in the drop shortcut task bar to open or close the projection.

- closed, after the end of the call, you need to manually open the projection to continue to use
- In the open projection state, the projection will be unstable when the phone battery power is less than 15%, it's caused by insufficient power so the user is required to charge in time to ensure adequate power.

### 2.Remote Control Wizard

This phone supports the remote control function of TV, TV box, air conditioning, DVD, audio and other infrared receiving equipment. You don't need to worry about the troubles caused by forgetting the hom appliance remote control. It can replace almost all househol appliances remote control, so that life becomes more comfortable and

### 3.WLAN

use WLAN on your phone, you must connect to a wireless access poin

## When you need to share the video, pictures, documents in the phone,

- automatically, slide off the projection lens cover, the projection is
- Open or close projection in Settings > projection menu (Notice:
- Click on the APP icon in the application interface to open or close the

Notice: The availability and coverage of WLAN signals is dependent on the numbers, the infrastructure, and the penetration object of other

### 4. Video Phone

Video phone is a communication mode based on internet and mobile the other side picks up the phone and then they can make a video call through the camera.

### 5.Conference Call

- Also known as two-way call / conference call, this function requires SIM card to be opened with conference call function
- The phone is with the one-way call function already
- Click "add call", dial a one-way call again (or pick up an incoming call the mobile phone enabled by default "call waiting" (settings - call settings - voice call - other settings), when the two-way calls is established, you can view the status on the call interface.
- After the establishment of a multi-party call, you can enter the menu by the small arrow, to separate the phone or hang up a phone call.

saved in the form of a chat record "conversation", rather than the usual folder structure. The message received would be displayed on the left side of the dialog, and the message sent would be displayed on the

Send MMS to other numbers: The newly created message is SMS the user can select or upload pictures, sound, text etc. and edit, when edit is finished, the message would be automatically turned to MMS, and then you can click "send" to send.

Message group sending to multiple numbers: You can input multiple numbers into the input box directly each number should be separated by comma in English. Click the icon on the right side of the recipient you can choose the contacts from the contact list for group sending.

### 7.Browser

Click the browser icon and enter the start page of the browser.

- Click on the web thumbnail image or input the website you want to access in the address bar (such as www.danew.com) and click the start button or
- To open a new browser window, click on the blank page to display the menu, please click the tab window icon on the menu, click the plus icon
- To switch to a new browser window, click on the blank page to display
- the menu, please click tab window icon on the menu, select the window you want to switch to.
- General settings, including homepage settings and other functions.
- Privacy and security, including the removal of historical records, to clear the cache and other functions.
- Auxiliary functions, including text size, point press to scaling and other
- Bandwidth management, to load the pictures or not when enter the web

## 8. Using the Phone Storage as U Flash Disk

nemory card, you have to set the phone storage card to U flash disk

store music, photos, and other files into your memory card or the built-in

Selecting the option to use as a USB storage device can open the right

You can view camera pictures directly in the PC side when it's

## Set Your Mobile Phone

## 1.Wireless & network

SIM card management Menu options for selecting or disabling SIM card 1 or SIM card 2, the

Bluetooth switch and settings
Touch the Bluetooth icon, enabled devices nearby the Bluetooth will

the mobile data services will be automatically shut down when the

## 2.Equipment

Profiles
This option provides you ringing settings for a phone call, notification, etc., including vibration, volume, ring tones, notification ring tones, and feedback (press the button, select, screen lock, touch), so as to adapt

Brightness Adjust the screen brightness Wallpaper You can set your mobile wallpaper from wallpaper galler gallery program or live wallpaper gallery.

Auto Rotate Screen Rotate the direction of mobile phone.

dibernation Adjust the delay before the screen is automatically locked. Font size Set the font size of the system.

You can view the use of TF card and mobile phone storage. ou can uninstall or format the TF card.

To show the boot time and the general use situation of the various

You can choose the default storage

Management application Applications to manage and remove other

Permission to access my location information:

there will be simple description and examples at the first time to set the unlock pattern, click "next" to the follow-up steps to draw the unlock

card. If not provided, the password should be obtained from the service

Personal dictionary Add words to your personal dictionary and delete words from the user's 

## 3.Personal

1) Access location information

## GPS satellite positioning: Open and close the GPS satellite positioning.

Set up screen lock:
Use a pattern, PIN, or a password to lock screen. Touch the "pattern",

Fingerprint unlock:
According to the tips and instructions, set the fingerprint to wake up the

SIM card lock.
Enter (4-8 bit number) PIN can set the SIM lock.
PIN in SIM card (personal identification number) is to prevent the illegal
use of SIM card. PIN is usually supplied with the SIM card. The initial then enter the password change interface, the phone will automatically prompt the old PIN input as well as the requirements of the input of the new PIN twice, and finally the phone will be prompted to modify the PIN successfully. If you input the wrong PIN three times , PIN in SIM card will be automatically locked. PUK code is usually supplied with the SIM

Notice: If you enter the wrong PUK code for 10 times in a row, the SIM

## 3) Language and input method

Select language: Including simplified Chinese and traditional Chinese, default support to

dictionary.
You can press the "+" button to add the word, then the input method will

## **Default input method setting:**You can choose the keyboard input method to be the default input

Android keyboard setting: Voice search: Set the search language, filtering pictures and text.

4) Backup & Restore Backup my data: Can be used for data backup and restore the factory settings

Notice: Backup your personal data before restore factory settings so as not to cause damage. 4.System

## omatically or manually confirm the time, time zone, and set the time 2: Time setting: You can set the timer on / off time, you can also choose the timing

switch onset time, repeat or a week of a certain day. 3: Auxiliary function: Large font: Displayed by large font. Press the "power" button to end the call: When you make a call, press

the "power" button to end the call rather than close the screen Touch and hold delay.

Install web script. Fast boot: Closed / open fast boot function 4: About mobile phones:
To update the system wireless, view model, version and other

Mobile Phone Application Notice Your phone is a product with excellent design and process, a be used carefully. The following advice can help you to fo warranty and prolong the service life of your mobile phone.

- Keep your cell phone dry, rain, moisture and all kinds of fluids that may contain minerals that will erode the electronic circuitry.
- 5) Do not put the phone in an environment of low temperature. When the temperature rises, the internal phone will be able to generate water vapor to damage the electronic line.
- 10) Use a clean, soft, dry cloth to clean the camera. Do not use harmful chemicals, cleaning agents and other liquid to clean the
- 14 ) Do not project to the human eye when you open the projection, to

- 1) Put the mobile phone and its parts in a place where children
- Do not use wet hands to touch the phone when the battery is charged, it will cause an electric shock damage to people or damage to the phone.
- Do not put the phone in an environment of high temperature. The high temperature will shorten the life of electronic equipment, damage the battery, distort or melt some plastic parts.
- 6) Do not put the phone in the vicinity of a lighted cigarette, an open Do not disassemble the cell phone, non professional treatment will lead to damage to the phone.
- 9) Do not use paint on the phone, because the paint will block the headset, microphone or other mobile accessories, and lead to the phone can't be used in a normal way.

8) Do not drop from a height, knock or shake the phone, rude way of use will damage the internal circuit boards.

- 11) Failures, such as mobile phones, batteries, chargers or mobile phone accessories, please send to the nearest qualified service center for inspection.
- 12) Service center staff will provide you with help, if necessary, will arrange maintenance for the phone. 13) Only to update the operating system that releases by Super Grand, do not re-install the system yourself, otherwise the

## Environment-Eriendly Instruction

1	Environ	mient	-i ileile	ary illa	tructio	1115		
nd should	Name and content of toxic substances or elements in the p							
ollow the	Part Name	(Pb)	(Hg) (Cd) (Cr(VI)) (PBE	(PBB)	(			
iren can't	Phone shell	0	0	0	0	0		
	PCBA	0	0	0	0	0	Ė	

LED screen O O O

Charger x O O O O Data cable O O O O O

"O" means that the content of the toxic and harmful substances in all homogeneous materials of this part is under the limited requirements of the SJ/T11363-2006. (" means the toxic and harmful substances at least in one of the demand of the SJ/T11363-2006, the reason is there's no mature

ternative technologies in the industry, but this part still conforms to the

The environment-friendly use period of the product is 20 years. The environment-friendly use period of the battery and other parts of the product may be different from the product's environment-friendly use period. Only when this product is used in the normal condition of the

After sales service address:

After sales service Tel:

Danew official website:

0899 782 728

www.danew.com

14 rue de la perdrix, 93420 Villepinte, France.

าร		Access	sory List	
ents in the	e product	No.	Item	Amount
(PBB)	(PBB)	1	Mobile phone	1
_		2	Travel charger	1
0		3	USB charging data cable	1
0		4	Earphone	1
0		5	User instruction	1
0	0		Warranty card	1

## SIM card & TF card thimble

contract with the dedict for de	rtano.		
Size	154mm×75mm×10mm		
Brightness	80 lumens HD projection		
Projection Resolution	WVGA (854*480)		
LCD screen	5.5" HD screen, 1920*1080 pixels		
Туре	Bar		
Antenna	Built-in		
SIM card	Micro SIM card (dual SIM card)		
Network mode	6 mode 17 frequency		
Built-in camera	Rear 13 AF, Front 8 AF, F2.0 aperture		
CPU	MT6753 OctaCore 64bits 1.5Ghz		
Operating system	Android OS 5.1		
Memory	3GB RAM+32GB ROM, TF card 64G		
The image processor GPU	Mali-T720		
Battery capacity	lithium polymer battery 4500mAh		
WIFI	IEEE802 11a/b/g/n, 2.4G/5G dual-band WIFI		
Wireless LAN	2.4GHz / 5GHz		
Plustoath	Support Bluetooth 4.0		

Regulatory Information Regulatory Information Your Danew mobile device is designed to comply with national regulatory requirements and international standards. For full compliance statements and details, please refer to the regulatory information in your product guides. **European Union Directives Conformance Statement** 

# The following CE compliance information is applicable to Danew mobile devices that carry one of the following CE marks:

**( €** 0700 **(**)

All other relevant EU Directives For products that support Wi-Fi 802.11a/ac (as defined in your product information): Outside the United States, this device is restricted to indoor use when operating in the 5.15 to 5.25 Ghz (802.11a/ac) Wi-Fi

# Please don't dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. Warning: Never dispose of batteries, either separately or within a mobile device, in a fire because they may explode. Mobile devices or electrical accessories should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Or, you may return unwanted Danew mobile devices and electrical accessories to any Daney Approved Service. Center in and electrical accessories to any Danew Approved Service Center in

Disposal & Recycling

## This product is RoHS compliant

Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

Head SAR

Body SAR

YOUR MOBILE DEVICE MEETS FCC AND IC LIMITS FOR EXPOSURE TO RADIO WAVES.

rour mobile device is a faciol transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) adopted by the Federal Communications Commission (FCC) and Industry Canada (IC). These limits include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the FCC and IC guidelines for your device model are listed helpow."

During use, the actual SAR values for your device are usually well below the values stated. This is because, for purposes of system efficiency and to minimize interference on the network, the operating

If you are interested in further reducing your RF exposure then you can easily do so by limiting your usage or simply using a hands-free kit to keep the device away from the head and body.

0,183 W/kg

0,603 W/kg